
For Models: GC3SHEXNQ04, GC3SHEXNT04, GC3SHEXNB04, GC3SHEXNS04 (White) (Stainless Steel) (Biscuit) (Black) Whirlpool 31 9 35 15 13 Literature Parts 24 18 12 37 3 19 28 25 26


### **CABINET PARTS**

Illus. No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
1		Literature Parts Use & Care Guide	11 12	3400243 2307179		25	2307152	Hinge Assembly, Bottom-FC (Include #29 & 32)
		Installation Instructions Service & Wiring	13		(Includes # 34) Filler, Wrapper	26		Button, Water Filter
		Sheet Energy Guide		2223893W 2223893T	White		2260503W 2260503T	White Biscuit
	2220407	Modular Icemaker Service Sheet	14	2223893B	Grille	27	2260503B 2260526	Housing, Water
2		Front Roller Asm Left Side		2322206W 2322206T 2322206B	Biscuit	28 29	4396710 2307051	Filter Water Filter Door Closer, FC
3 4	2223263	Right Side Strap, Roller Roller, Rear (2)	15 16	3400108		30	2307051	Cap, Water Filter
5 6	2223388	Clip, Retainer (4) Clip, Grille		2307007W 2307007T			2260518W 2260518T	White
7 8	489478 2223545	Screw Shim	17	2307007B 489464	Screw	31	2260518B	Cabinet (Not A
9	2307008W		18 19 21	2254566	Drain Fitting Tube, Extension	32 34	489483	
10	2307008T 2307008B 3400113	Black	22 23	2223387	Cover, Unit Pin, Roller (4) Clamp, Service	35 36	3400858	
10	0400113	COICW	24	489084	Cord	37	2319868	Outlet

#### REFRIGERATOR LINER PARTS



### REFRIGERATOR SHELF PARTS



### FREEZER LINER PARTS

FREEZER LINER PARTS
For Models: GC3SHEXNQ04, GC3SHEXNT04, GC3SHEXNB04, GC3SHEXNS04
(White) (Biscuit) (Black) (Stainless Steel) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	2223777	Spacer, Slide (2)
2 3 6	3400893 2223690	
9	2223500	Basket, Deep (2) Shelf Assembly,
		Cantilever (2)
11 13	2223782	Front, Basket Shelf Track
13	2223787	Right Side
	2223788	Left Side
14 15	2223681 2223692	Shelf, Fixed Basket, Lower
16	489427	
17	842534	Clip, Air Duct (2)
18		Glide Assembly,
	2301544	Basket (2) Right Side
	2301545	Left Side
19 20	2259487 8534064	Cover, Emitter Screw
20 22	2198635	
23	2198634	Pin
24 25	2198665 1115373	
26	2220398	P.C. Board
		Emitter
27 28	2223321	Cover, Ice Maker Slide, Ice Maker
20		Mounting
	2212321	Right Side
29	2306900 489478	Left Side Screw
30	489214	Screw
32	2162085	Light Socket
33 34	2255743 8281185	Light Bulb Screw
35	2198633	Flipper
36	2255558	Cover, Receiver
37	2255562	Slide, Ice Maker Shut Off
38	2255114	
00	0400040	Receiver
39 40	2198643 2198589	Lens Light Shield
41	2212340	
42	2198641	Bracket, Ice Maker
43	2155597	Cover Socket, Light
45	2.00007	Ladder
	2320024	
46	2320025 2303378	
.0	_000070	C. Hold, Trilling

### **MOTOR AND ICE CONTAINER PARTS**

For Models: GC3SHEXNQ04, GC3SHEXNT04, GC3SHEXNB04, GC3SHEXNS04 (White) (Biscuit) (Black) (Stainless Steel) - 19 22-24 2 -26 -36 20 21 -30 3 4 37 18-18 31 6 5 32 7 5 9 23 10 -33 9 23 14 - 15 -16 - 17

### **MOTOR AND ICE CONTAINER PARTS**

Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 26 30 31 32 33 36 37	2223317 2255574 2320327 2258220 1119007 2255460 2257022 1119005 2257020 2257023 2198602 489229 2257024 489235 2198661 2188918 8281164 3400065 2255575 2212371 2198608 2198671 8281163 2188919 2198628 2188916 2256154 2315547 2212305 2315559 2187725	Auger Washer Spacer, Flat (6) Cover, Crusher Blade, Rotary Spacer, Step (2) Blade, Fixed Blade, Rotary Block, Blade Roll Pin Blade, Rotary Washer, Plain Washer, Coupling Coupling Screw Screw Button, Bin Latch, Bin Spring, Latch Screw Screw Screw


### **REFRIGERATOR DOOR PARTS**

For Models: GC3SHEXNQ04, GC3SHEXNT04, GC3SHEXNB04, GC3SHEXNS04 (White) (Biscuit) (Stainless Steel) (Black) 13 21 10 3 11 6 5 18 11 9 16 12 20 17 <u>`</u>15 14

### **REFRIGERATOR DOOR PARTS**

Illus No.	. Part No.	DESCRIPTION
1		Refrigerator Door
		(Includes #7)
	2307196W	White
	2307196T	Biscuit
	2307196B	
	2322201S	
2 3 4	2203087K	,
3	2255421	
4	2223463K	Door Bin
5	2223464K 2255411	Mat, Bin (3)
6 7	2255411	Clip, Mounting Door Gasket,
'		Magnetic
	2223841	Mist Beige
	2223911	Black
8	2220011	Handle
•		(Includes #9)
	2305993W	
	2305993T	Biscuit
	2305993B	Black
9	8533920	
10	2223879	
11	489491	
12	2307048	Door Closer,
4.0		Upper Cam
13	2308091	Thimble, Top
14 15	489420	Screw Bracket, Door Stop
13	2306940	
	2306940B	
16	2304952K	
17	3400012	
18	2224173	Door Bin,
-		Shallow
20	2156006K	Plug, Trim
21	2220214	Nameplate


### FREEZER DOOR PARTS



## FREEZER DOOR PARTS

Illus No.	. Part No.	DESCRIPTION
1		Freezer Door
		(Includes #8 And Dispenser
		Front Parts)
	2320117W	White
	2320117T	Biscuit
	2320117B 2320123SB	
2	232012330	Handle
_		(Includes #6)
	2305993W	White
	2305993T	Biscuit
3	2305993B 2255411	
3 4	489491	
5	3400012	
6	8533920	
7 8	2171157K	
Ö		Door Gasket, Magnetic
	2223850	
	2223912	
9	2223334	Trivet,
40	0040000	Tilt-Out (2)
10 11	2219982 2308091	,
12	2304309	Basket,
	_00.000	Tilt-Out (2)
13	2255459K	Bottle, Ice Pack
14	2307050	
15	2304895	Upper Cam Safety Barrier
16	489420	
17	100 120	Bracket, Door Stop
	2306940	Chrome
	2306940B	Black


### **DISPENSER FRONT PARTS**




### **DISPENSER FRONT PARTS**


Illus No.	. Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2 3 4 5 6 7	3196537 2194719 2304772 2196195 2180353 2304355	Screw Retainer, Levers Spring, Torsion Pin Door, Ice Door Mechanism
8 9	2205686 2206670W 2206670T	
10	2206670B 2209718	Black
11		Lever, Ice Dispenser
12 13 15 17	2255431W 2255431T 2255431B 2180224 2305571 2323009	Biscuit Black Guide, Ice Gasket
19	2255432W 2255432T 2255432B	White Biscuit Black Overlay, Front Cover (Not Available,
20		Order #23) LED Display (Not Available,
21		Order #23) Front Cover, Housing (Not Available,
22 23	489000	Order #23) Screw Front Cover Assembly (Includes Items
24 25 26 27	2224183W 2224183T 2224183B 2304673 2195051 3400065 2252127	13, 19, 20 & 21) White Biscuit Black Bracket, Dispenser Strain Relief Screw

#### **AIR FLOW PARTS**




### **CONTROL PARTS**





Illus. No.	Part No.	DESCRIPTION
1	2319752	Control Box
		(Includes #6)
2	2223877	Latch
3	2306952	Trim, Control Box
4		Spring, Torsion
5		Heat Shield Asm
6	2307037	Control Board Asm
10	2223506	Light Lens,
		Control Box
17	2223857	Light Socket
19		Light Bulb

### **UNIT PARTS**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

### **UNIT PARTS**

	TION
1	ustrated Included ess ess ess ess ess ess ess



### **ICEMAKER PARTS**



### **ICEMAKER PARTS**

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting, Water Tube
5	628379	Clip, Fuse
9 10	489478	
14	2315533 2208136	
18	2174358	
19	488649	
20	628228	
		Assembly (Also
		Order 542638)
22	628356	
23	627843	
24	2198598	
25 26	2194712 2315522	
20	2310022	Thermostat
27	627985	
	02.000	Order 542369
		Cement
		Alumilastic)
28	8533917	
30	489276	
32	2187467	
33	2303583	Bracket, Icemaker
35	626678	Mounting Module Assembly
33	020076	(Includes Items
		37 & 38)
37	626676	
38	489136	Screw
100	2198597	Icemaker Assembly

#### **OPTIONAL PARTS**

For Models: GC3SHEXNQ04, GC3SHEXNT04, GC3SHEXNB04, GC3SHEXNS04 (White) (Biscuit) (Black) (Stainless Steel)

Illus.PartIllus.PartIllus.PartNo.No.No.No.DESCRIPTIONNo.No.DESCRIPTION

# PAINT, PRESSURIZED SPRAY (12 oz.)

\*350942 Primer, White \*350939 Black \*350930 White \*4392901 Biscuit \*8171357 Graphite

#### PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black 4392899 Biscuit 80051 Graphite

\*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.

#### **Refinishing Material**

799340 Black 799344 White 4392900 Biscuit 8171358 Graphite

#### **Miscellaneous**

212643 Sealer, Gum (4 Feet) 479502 Tape, Vinyl  $(3/4 \times 108'')$ 505587 Sealer, Mastic (1 Qt.) 503695 Cork, Sealer (1/4 Pound) 542638 Grease, Silicone (1/2 Oz.) 542639 Cement, Alumilastic (1-1/4 Oz.)799833 Kit, Evaporator Repair (Aluminum Epoxy) 833938 Kit, Terminal Connector

#### **TORX SCREW WRENCH**

1117510 Torx Key